


Keep top screw loose until AnoGotcha rail is positioned correctly on clamp as shown here.

Be sure top and bottom Gotcha face outwards.

Adjust pole height by loosening and tightening telescoping lock.



*Same assembly for both round and square profile.

