

# IMPORTANT

Please read this document *before* using your **FloorWindo® 5-Series**

## INSTRUCTIONS FOR USE, ASSEMBLY AND MAINTENANCE\*

- Recommended weight of paper stock for insert is 80–120 lb. offset, coated or glossy paper stock.
- **Please ensure the ink on your printed graphic is completely dry** (at least 24 hours) before inserting into FloorWindo.
- Remove the foil from the backside of your FloorWindo before using.
- Insert graphic as shown below.
- Place the FloorWindo only on a dust-free, dry, flat surface.
- Only use indoors and in dry conditions.
- Clean your FloorWindo on a regular basis, use a damp microfiber cleaning cloth or a non-scratching detergent and a clean dry cloth.
- Never use a damaged FloorWindo.
- Always store your FloorWindo display mat flat.

It is recommended placing the FloorWindo just outside of high traffic walking areas. This will help reduce wear and increase the life of your FloorWindo while still creating maximum impact for your message.



Load your graphic insert like this.



\*If the instructions for use, assembly and maintenance are not carried out, Rose Displays, is not liable. Rose Displays is never liable for indirect damages. Visit [RoseDisplays.com](http://RoseDisplays.com)

Please file these instructions for future reference.

**rose** | displays  
The Signware® Specialists

# IMPORTANT

Please read this document *before* using your **FloorWindo® Next Generation**

## INSTRUCTIONS FOR USE, ASSEMBLY AND MAINTENANCE\*

- Recommended weight of paper stock for insert is 80–120 lb. offset, coated or glossy paper stock.
- **Please ensure the ink on your printed graphic is completely dry** (at least 24 hours) before inserting into FloorWindo.
- Remove the 2 transparent spacing tabs on the backside of the FloorWindo before using (A0 model only).
- Insert graphic as illustrated below.
- Place the FloorWindo only on a dust-free, dry, flat surface.
- Only use indoors and in dry conditions.
- Clean your FloorWindo on a regular basis, use a damp microfiber cleaning cloth or a non-scratching detergent and a clean dry cloth.
- Never use a damaged FloorWindo.
- Always store your FloorWindo display mat flat.



**1** Locate the opening under the LogoLip



**2** Slide the back panel from under the opening and lift the window away from the poster



**3** Exchange the poster like this



**4** Always keep your FloorWindo® clean

It is recommended placing the FloorWindo just outside of high traffic walking areas. This will help reduce wear and increase the life of your FloorWindo while still creating maximum impact for your message.



\*If the instructions for use, assembly and maintenance are not carried out, Rose Displays, is not liable. Rose Displays is never liable for indirect damages. Visit [RoseDisplays.com](http://RoseDisplays.com)

Please file these instructions for future reference.

**rose/displays**  
The Signware® Specialists